

Figure 1

TWAIN Source User Interface

Scanner Model A
<p>Scan Parameters</p> <p>Image Type: <input checked="" type="radio"/> Color <input type="radio"/> Black/White</p> <p>Resolution: <input checked="" type="radio"/> 300 <input type="radio"/> 400 <input type="radio"/> 600</p> <p>Size (inch): <input checked="" type="radio"/> 8.5 x 11.0 <input type="radio"/> 3.5 x 2.5</p>
<p><input type="button" value="SCAN"/> <input type="button" value="COMMAND A"/></p> <p><input type="button" value="CLOSE"/> <input type="button" value="COMMAND B"/></p>

Figure 2




Figure 3A




Figure 3B

Vertically
Tiled Images




Figure 3C


Horizontally tiled images

TWAIN Source User Interface

Scanner Model A	
Scan Parameters	
Image Type: <input type="radio"/> Color <input checked="" type="radio"/> Black/White	
Resolution: <input type="radio"/> 300 <input type="radio"/> 400 <input type="radio"/> 600	
Size (inch): <input type="radio"/> 8.5 x 11.0 <input type="radio"/> 3.5 x 2.5	
52	<input checked="" type="checkbox"/> Scan Multi-Sided Card Numer of Sides: <input type="radio"/> 2 <input type="radio"/> 3 <input type="radio"/> 4 Tile images: <input type="radio"/> Horizontally <input checked="" type="radio"/> Vertically
54	<input checked="" type="checkbox"/> Auto-Start scan when card is on scanner
SCAN COMMAND A	
CLOSE COMMAND B	

Figure 4

Figure 5






Figure 6




Figure 7




Figure 8